


CHECKING IRT/C AMBIENT TEMPERATURE

In many installations, it may not be clear whether cooling is required, and it may not be easy to obtain the temperature of the environment experienced by the IRT/c. The IRT/c itself will tell you what its own temperature is, by using the procedure illustrated below.

The basic method is to temporarily “blind” the IRT/c using aluminum foil, so that it can only see itself. The temperature that it produces is then its own temperature only.

Before running this test, be sure to check for leakage current offsets as described in the manual.



Exergen Global offices:

The Netherlands
Pastoor Clercxstraat 26
5465 RH Veghel
Tel: +31(0) 413 37 65 99
Fax: +31(0) 413 37 93 10

USA
400 Pleasant Street
Watertown, MA 02472
Tel: +1 617 649 6322
Fax: +1 617 923 9911

office@exergenglobal.com
www.exergenglobal.com