


HP15


SL 3.0

Double single-level thermostat

Handbook



MAIN SETTINGS (Run Mode).



SET 1 TEMPERATURE SETTING.

Press **SET 1** (key lamp flashes):


This message will be displayed instead of the °Set 1 temperature value.

Press + or - to modify. Press **SET 1** to confirm.

SET.1

25.0°C

Example SET.1 = 25.0°



SET 2 TEMPERATURE SETTING.

Press **SET 2** (key lamp flashes):

This message will be displayed instead of the °Set 1 temperature value.

Press + or - to modify. Press **SET 2** to confirm.


SET.2


25.0°C

Example SET.2 = 25.0°


MINIMUM AND MAXIMUM AMBIENT TEMPERATURES RECORDING.

TEMPERATURE 1 RECORDING VIEWING. Press **SET 1** key, after:





Press & hold +  : will be displayed followed by °Maximum Temperature 1 Recording.




Press & hold -  : will be displayed followed by °Minimum Temperature 1 Recording.

TEMPERATURE 2 RECORDING VIEWING. Press **SET 2** key, after:



Press & hold +  : will be displayed followed by °Maximum Temperature 2 Recording.



Press & hold -  : will be displayed followed by °Minimum Temperature 2 Recording.

Values recorded are permanently stored in the memory. To clear memory push + key for more than 3 seconds: **CLEA** message will be displayed before clearing operation.

COST PROGRAMMING (System constants)



These settings refer to the mode operation of the system and must be made on initial start-up.



Press - / + together for at least one second: the message **C.O.S.t.** will be displayed.



Press **SET 2** repeatedly until desired variable's message is displayed (see table below) : variable value and related message will be displayed.

Press + or - to set a new value and then **SET 2** to confirm.

The next system constant will then appear.

You can press **SET 2** for a least two seconds to escape and return to the *Run Mode*.

Mess.	Value	Meaning	Note
diF.1	0.2°	° SET 1 differential	*1)
diF.2	0.2°	° SET 2 differential	*1)
tEnP	=1	Temperature representation (=1 °C, =2 °F)	*2)
Ad.t1	0.0°	° Zone 1 input temperature sensor correction (+ or -)	*3)
Ad.t2	0.0°	° Zone 2 input temperature sensor correction (+ or -)	*3)

*1) For more details see *Operating Diagrams*.

*2) tEnP =1 : °C Temperature range.
tEnP =2 : °F Temperature range.

*3) You can correct the readings on the various sensors (+ or -).

PRESET PROGRAMS (Bootstrap)



This processor is ready programmed with the following (variable) settings.

To return to these settings at any time:

Power off the processor, press **SET 2** key and keep it pressed giving power on: release **SET 2** key when the **boot** message appears.

SEt.1 = 25.0° SEt.2 = 25.0°


The **COS.t** values are shown in **COS.t** paragraphs.

STATE INDICATION LAMPS

The lights situated at the bottom of the display show the state of the various relays as set out below.

Lamp.	State	N° Relay	Contacts
HEAT (1)	HEAT 1 Output On	1	3-4
COOL (1)	COOL 1 Output On	1	4-5
HEAT (2)	HEAT 2 Output On	2	6-7
COOL (2)	COOL 2 Output On	2	7-8

OPERATING DIAGRAMS



INSTALLATION

How to connect the sensors

Connect the sensors provided as shown in the diagram.

For remote connections use a standard 0.5-square millimetre two-pole wire for each sensor, taking great care over the connections, by insulating and sealing the joins carefully.

How to connect the line


Connect 230V line on terminals L-N.

Protect supply with adequate fuse.

How to connect the contacts

Connect terminals on the terminal block

(contacts up to 4AMP.AC1) to the loads as shown in the diagram.



* Other power voltage if you required

Troubleshooting

-O.C.- is displayed when the temperature sensor wiring is open circuited.

-S.C.- is displayed when the temperature sensor wiring is short circuited

Unit 6, Old Wharf Ind. Estate, Dymock Rd, Ledbury HR8 2JQ
Tel. 01531 631161 e.mail: climatec@climatec.co.uk