

"HAND" MODE

In some start-up conditions may be useful to work in "hand" mode:

Power off the processor, press **+** key and keep it pressed giving power on: **HAnd** message will be displayed (release now **+** key).

Push **+** until is displayed number required to be handed (see table relays) and push **ALARM** for activating relay.

Pushing again **+** for increase relay number previous relay is disactivated.

You can press **ALARM** key for a least two seconds to escape and return to the *Run Mode*.



STATE INDICATION LAMPS

The light situated at the bottom of the display show the state of the various relays as set out below:

Lamp.	State	N° Relay	Contacts
CLOSE (1)	Close (Heat) Zone 1 On	1	3-4
OPEN (1)	Open (Cool) Zone 1 On	2	5-6
CLOSE (2)	Close (Heat) Zone 2 On	3	7-8
OPEN (2)	Open (Cool) Zone 2 On	4	9-10
MIN (1)	Minimum Alarm Zone 1 On	EXT2 (*)	6-7-8
MAX (1)	Maximum Alarm Zone 1 On	EXT2 (*)	6-7-8
MIN (2)	Minimum Alarm Zone 2 On	EXT2 (*)	6-7-8
MAX (2)	Maximum Alarm Zone 2 On	EXT2 (*)	6-7-8
	Logic Or On relays 1-2-3-4	EXT1 (*)	3-4-5

* Available only with **HPAL** optional slot

INSTALLATION

How to connect the sensors


Connect the sensor provided as shown in the diagram. For remote connections use a standard 0.5-square millimeter two-pole wire, taking great care over the connections, by insulating and sealing the joins carefully. **-O.C.-** is displayed when the temperature sensor wiring is open, **-S.C.-** is displayed when the temperature sensor wiring is short circuit.

How to connect the line

Connect 230V line on terminals **L-N**. Protect supply with adequate fuse.

How to connect the contacts

Connect terminals **3-4..9-10** on the terminal block (contacts up to 4AMP.AC1).




*Other power voltage if you required.

HP26

SL 3.0

Double floating proportional

Handbook



MAIN SETTING (Run Mode)

ZONE 1 TEMPERATURE SETTING



Press **SET 1** (key lamp flashes):

this message will be displayed instead of the ° Set Zone 1 temperature value.

Press **+** or **-** to modify, press **SET 1** to escape.

SET.1

ZONE 2 TEMPERATURE SETTING




Press **SET 2** (key lamp flashes):

this message will be displayed instead of the ° Set Zone 2 temperature value.

Press **+** or **-** to modify, press **SET 2** to escape.

SET.2

ALARM PARAMETER SETTING



Press **ALARM** (key lamp flashes):

this message will be displayed instead of the ° Set Zone 1 Minimum alarm temperature value.

Press **+** or **-** to modify, press **ALARM** to confirm.

AL.1

At this point:

this message will be displayed instead of the ° Set Zone 1 Maximum alarm temperature value.

Press **+** or **-** to modify, press **ALARM** to escape.

AL.1

At this point:

this message will be displayed instead of the ° Set Zone 2 Minimum alarm temperature value.

Press **+** or **-** to modify, press **ALARM** to escape.

AL.2


At this point:

this message will be displayed instead of the ° Set Zone 2 Maximum alarm temperature value.

Press **+** or **-** to modify, press **ALARM** to escape.

AL.2

COST PROGRAMMING (System costants)



These settings refer to the mode of operation of the system and must be made on initial start-up.

Press **- / +** together for at least one second: the message **C.O.S.t.** will be displayed.

Press than repeatedly **ALARM** until interested variable's message is displayed (see table below): variable value and related message will be displayed.

Press **+** or **-** to set a new value and then **ALARM** to confirm. The next system constant will then appear.

You can press **ALARM** for a least two second to escape and return to the Run Mode.



Mess.	Value	Meaning	Note
n.b.1	0.2°	° Zone 1 Neutral range	*1)
b.CL.1	5.0°	° Zone 1 HEAT modulation range	*1)
b.OP.1	5.0°	° Zone 1 COOL modulation range	*1)
t.on.1	1.0"	Zone 1 On time in seconds	*1)
t.oF.1	60.0"	Zone 1 Off time in seconds on exit from neutral range	*1)
n.b.2	0.2°	° Zone 2 Neutral range	*1)
b.CL.2	5.0°	° Zone 2 HEAT modulation range	*1)
b.OP.2	5.0°	° Zone 2 COOL modulation range	*1)
t.on.2	1.0"	Zone 2 On time in seconds	*1)
t.oF.2	60.0"	Zone 2 Off time in seconds on exit from neutral range	*1)
tEnP	=1	Temperature representation (=1 °C, =2 °F)	*2)
Ad.t1	0.0°	° Zone 1 input temperature sensor correction (+ or -)	*3)
Ad.t2	0.0°	° Zone 2 input temperature sensor correction (+ or -)	*3)

*1) For more details see *Operating Diagrams*.

*2) **tEnP =1** : °C Temperature range.

tEnP =2 : °F Temperature range.

*3) You can correct the readings on the sensor (+ or -).

PRESET PROGRAMS (Bootstrap)



At delivery this processor is ready programmed with the following (variable) settings.

To return to these settings at any time:


Power off the processor, press **ALARM** key and keep it pressed giving power on: release **ALARM** key when on the screen appear **boot** message.

SEt.1=25.0° SEt.2=25.0° AL._1=10.0° AL.-1=40.0° AL._2=10.0° AL.-2=40.0°

The **COSt** values are shown in *COSt Programming*


OPERATIVE DIAGRAMS

Floating poportional action




On-Off actioning (Heating and Cooling)

With **t.on.x=0.0"** (x referred to Zone 1 or 2) you can obtain actioning of Heating and Cooling in On-Off mode.



Alarm temperature actioning



Alarm output available only with **HPAL** slot option.

Note: these impostations referrig to ZONE 1 or ZONE 2:
For example: **SEt.1** referring to Zone1, **SEt.2** referring to Zone 2).