

STATE INDICATION LAMPS

The light situated at the bottom of the display show the state of the various relays as set out below:

Lamp.	State	N° Relay	Contacts
HEAT (*1)	HEAT On	1	3-4
COOL	COOL On	2	5-6
HUM	HUM On	3	7-8
DEHM (*1)	DEHM On	4	9-10
MIN	MIN ALARM On (n.c.)	7 *	6-7-8 *
MAX	MAX ALARM On (n.c.)	7 *	6-7-8 *
C.AIR	CHANGE AIR On	6 *	3-4-5 *
IDEAL	Ok temperature		

(*) Available only with HPAL optional slot.

(*1) Action light (HEAT-COOL) flash during delay time (see **COST** function **t.on-t.Of**).

INSTALLATION

How to connect the sensors


Connect the sensor provided as shown in the diagram. For remote connections use a standard 0.5-square millimeter two-pole wire, taking great care over the connections, by insulating and sealing the joins carefully. **-O.C.-** is displayed when the temperature sensor wiring is open, **-S.C.-** is displayed when the temperature sensor wiring is short circuit.

How to connect the line


Connect 220V line on terminals **L-N**. Protect supply with adequate fuse.

How to connect the contacts


Connect terminals on the terminal block (contacts up to 4AMP.AC1)



RHP sensor probe connection



4-20mA sensor probe connection



* Other power voltage if you required

As it company policy to continually improve the products the Manufacturers reserve the right to make any modifications thereto without prior notice. They cannot be held liable for any damage due to malfunction.


POLA® CE EMC LVD 981116

HP47

SL 2.0
Handbook




Thermal chamber controller



MAIN SETTING (Run Mode)

TEMPERATURE SETTING




Press **TEMP** (key lamp flashes):

this message will be displayed instead of the **Set temperature value**.

Press **+** or **-** to modify, press **TEMP** to confirm.

°
t.SET

HUMIDITY SETTING.




Press **HUM** (key lamp flashes):

this message will be displayed instead of the **%RH Set Humidity value**.

Press **+** or **-** to modify, press **HUM** to confirm.

H.SET

ALARM TEMPERATURE SETTING.



Press **ALARM** (key lamp flashes):

this message will be displayed instead of the **Set Minimum alarm temperature value**.

Press **+** or **-** to modify, press **ALARM** to confirm.

°
AL._.

At this point:

this message will be displayed instead of the **Set Maximum alarm temperature value**.

Press **+** or **-** to modify, press **ALARM** to exit.

AL.°

TEMPERATURE AND PROGRAM STATE VIEWING

With **TEMP** key lamp light (press **TEMP** key) ambient temperature is displayed.





With **HUM** key lamp light (press **HUM**) ambient humidity is displayed.

For viewing other parameters press these keys for at least two seconds:

Key	Message	Meaning	Notes
TEMP	t.AuS	° Aux Temp viewing	(*1)
HUM	t.---	° Max Heat viewing	
ALARM	C.Air	C.Air minutes count down	not in C.AIR
"	On.C.A	C.Air end minutes	in C.AIR
"	-oF-	C.Air not active	



*1) This probe show only Aux. temperature.

VIEWING TEMPERATURE RECORDING

 Press + :  will be displayed followed by °Maximum Temperature Recording.
 Press - :  will be displayed followed by °Minimum Temperature Recording.

Values recorder are memory permanent stored: for memory clear keep pushed + keys for more than 3 seconds: **CLEA** message will be composed on display before clearing operation.

COST PROGRAMMING (System constants)

  These settings refer to the mode of operation of the system and must be made on initial start-up. Press - / + together for at least one second: the message **C.O.S.t.** will be displayed.
 Press than repeatedly **ALARM** until interested variable's message is displayed (see table below) : variable value and related message will be displayed.
 Press + or - to set a new value and then **ALARM** to confirm.

The next system constant will then appear.

You can press **ALARM** for a least two second to escape and return to the *Run Mode* .

Mess.	Value	Meaning	Notes
r.HEA	-1.0°	° HEAT setting referring to t.SET	*1)
r.COL	1.0°	° COOL setting referring to t.SET	*1)
r.Hun	-5.0H	%RH HUM referring to H.SET	*1)
r.dEH	5.0H	%RH DEHM referring to H.SET	*1)
d.HEA	0.5°	° HEAT differential	*1)
d.COL	0.5°	° COOL differential	*1)
d.Hun	1.0H	%RH HUM differential	*1)
d.dEH	1.0H	%RH DEHM differential	*1)
t.HEA	25.0°	° Max Heat set (Max Heat On)	*2)
n.CHA	0	Daily number C.AIR	*3)
d.CHA	0'	Minutes dutation C.AIR	*3)
Huny	=1	Humidity sensor type	*4)
tEnP	=1	Temperature representation (=1°C, =2°F)	*5)
Ad.t1	0.0°	° Input ambient temperature correction (+ or -)	*6)
Ad.Hu	0.0H	%RH ambient humidity correction (+ or -)	*6)
Ad.t3	0.0°	° Input Max Heat temperature correction (+ or -)	*6)
Ad.t4	0.0°	° Input Aux temperature correction (+ or -)z	*6)

*1) For more details see *Operating Diagrams*.

*2) Over this temperature **HEAT** and **DEHM** are Off (Max Heat On): in this condition lamps **HEAT** and **DEHM** are flashes.

*3) Available only with **HPAL** optional slot.

*4) **HP47** can be configured in these different humidity sensor type:

Huny =1 : 0-20mA sensor (RHP type): direct connect.


Huny =2 : 4-20mA sensor: to call for a **HALI** power pack.

*5) **tEnP =1** ; °C Temperature range.


tEnP =2 ; °F Temperature range.

*6) You can correct the readings on the sensor (+ or -).

OPERATIVE DIAGRAMS



PRESET PROGRAMS

 At delivery this processor is ready programmed with the following (variable) settings. To return to these settings at any time: Power off the processor, press **ALARM** key and keep it pressed giving power on: **boot** message will be displayed (release now **ALARM** key).
t.SET = 10.0° H.SET = 80.0H AL._. = -50.0° AL.-. = 50.0°
COST value are shown in **COST** paragraph.

"HAND MODE"

In some start-up conditions may be useful to work in "hand" mode.

Power off the processor, press + key and keep it pressed giving power on:

HAnd message will be displayed (release now + key).

Push + until is displayed number required to be handed (see table relays "N° Relay") and push **ALARM** for activating relay.

Pushing again + for increase relay number previous relay is deactivated. You can press **ALARM** for a least two seconds to escape and return to the *Run Mode*.