

Fish Hawk X4/X4D Probe Battery Pack Replacement Instructions

Tools Needed:

1. Small knife or flat screwdriver
2. Needle nose pliers
3. Silicone adhesive

Instructions:

1. Completely remove black silicone adhesive that holds the battery pack connector in place with a small knife, needle nose pliers, or flat screwdriver.
2. Pull original connector straight off. Notice three gold prongs coming out of the probe body, use caution not to damage those prongs.
3. Line up the three holes on the new battery pack connector with the three gold prongs. Polarity doesn't matter as long as each pin is in a connector hole.
4. Using the needle nose, gently push the connector onto the three gold prongs.
5. Secure the connector in place with a fresh dab of silicone sealant.

Note:

1. When reinstalling the battery pack into the probe, make sure the wires come out of the back of the battery pack. This takes up the slack in the wires so they can not catch in the cap threads. See photo below

CORRECT INSTALLATION – wires out back of battery pack



Phone (218) 454-4760

Email graydenoutdoor@gmail.com