



Replacing Trim Molding & Bumper Cushion

Using a #2 Screwdriver unscrew the 5 screws on the metal chrome trim molding/edging.

Slide the chrome trim molding over to the left or right so the edge/end can be grabbed and pulled off.

This will expose the bumper cushion rail bolts.

Using a 7/16 ratchet unscrew the 3 rail bolts that is holding the damaged bumper cushion.

Replace the damaged bumper cushion with the new bumper cushion. Hold the cushion flush to the top edge of the laminate rail while securing with the existing rail bolts.

Slide the new chrome trim molding/edging back onto the rail and center. While holding flush to the top edge of the laminated rail, secure using the existing screws.