

PARTS

- A** side frame pieces - front - (2) 2 x 4 (see drawing)
- B** side frame pieces - back - (2) 2 x 4 (see drawing)
- C** lower side supports - (2) cut from 1 x 6 cedar (see drawing)
- D** horizontal supports - (3) 2 1/2" x 23" cut from 1 x 6 cedar
- E** tray backs & fronts - (6) 2 1/2" x 20" cut from 1 x 6 cedar
- F** tray sides - (6) 2 1/2" x 14" cut from 1 x 6 cedar
- G** tray bottoms - (6) 5 1/2" x 18 1/2" cut from 1 x 6 cedar

WHAT YOU'LL NEED

Tools

- mitre saw 1347-110
- measuring tape 1048-330
- drill 1239-120
- #8 screw setter 1227-513
- sander 1262-369
- bench saw 1346-634
- level 1036-335/336
- carpenter's square 1070-060

Material

- 1" x 6" cedar (rip to make supports and trays) 10' tray bottoms
- 9' tray sides, fronts & backs (rip)
- 6' back and side supports (rip)
- 2" x 4" cedar (16 feet)
- 1 1/2" deck screws 2182-083
- 3 1/2" deck screws (2) 2182-092
- 2" galvanized finishing nails 2134-835
- exterior wood glue 2020-150/151
- fine sandpaper 1233-196
- exterior wood finish/sealer 1877-838

