



**DETALE
CPH**

KABRIC

Instructions

Easy to apply and pleasing to your senses
Share your story #detalecph



Share your DETALE project

Share your DETALE project and find other inspiring projects on Instagram under #detalecph. We are happy to share your pictures & stories. Please send it to our email: hello@detalecph.com.

Follow our projects

Find us on Facebook or Instagram under DETALE CPH or visit us on www.detalecph.com. Please send all constructive feedback on hello@detalecph.com.

Preparation

The Surface on which KABRIC is to be applied, has to be smooth, dry and sustainable. An irregular surface must be evened out with a suitable plaster and absorbent surfaces must be primed.

Durability

KABRIC has a durability that is equivalent to a regular painted wall Shine 5. The product can, in most cases, be applied without any other treatment. For walls that are exposed to great wear and tear, we recommend you apply KABRIC Topcoat, as an additional treatment. The Topcoat can be purchased separately.



**DETALE
CPH**

Application with Trowel

You need

2 trowels of 15-35 cm in size
Paint roll to apply KABRIC
Plastic roller-tray or bucket to roll out the paint
Plastic and cardboard for covering
Tape
Sandpaper, grain 180-220

1

Set up tape around the desired area to cover. Apply KABRIC on the entire wall in one go, without pausing. KABRIC is applied with a paint roll, with asymmetrical lines, before the product is pulled out with a trowel. The method is repeated until the whole area is overlaid with a thin, covering layer. Make sure to have enough KABRIC on the paint roll, so you can easily measure out the product on the wall and make sure to avoid rolling paint on to large areas at the time, so you always work "wet-in-wet". Be aware that plastering spots and transitional areas can be seen clearly. Let the wall dry for a minimum of 3-4 hours before 2. layer is applied.

Tip: The finish depends on the way you apply KABRIC to the wall. Avoid applying in straight lines, but with smooth and soft curves.

2

If transitions are noticeable, sand these away before 2. layer of KABRIC is being applied. Apply 2. layer to the wall again, using the same method and technique. The thinner the 2. layer is, the more lifelike will the expression and finish become. Try to avoid making knobs and sharp edges.

Remove the tape before KABRIC dries and allow the wall to dry until the next day before Topcoat is applied, or shelves and pictures are to go up in the wall.

Application with Paintbrush

You need

1 large paintbrush of 10 cm in size, and a smaller paintbrush for application around edges.
Paint roll to apply KABRIC
Plastic roller-tray or bucket to roll out the paint
Plastic and cardboard for covering
Tape
Sandpaper, grain 180-220

1

Set up tape around the desired area to cover. Apply KABRIC on the entire wall in one go, without pausing. KABRIC is applied with a paintbrush, with asymmetrical lines before the product is pulled out and painted over with a paintbrush. The method is repeated until the whole area is overlaid with a thin, covering layer. Make sure to have enough KABRIC on the paintbrush, so you can easily measure out the product on the wall and make sure to avoid rolling paint on to large areas at the time, so you always work "wet-in-wet".

Tip: The finish depends on the way you apply KABRIC to the wall. Avoid applying in straight lines, but paint with smooth and soft curves.

2

If transitions are noticeable, sand these away before 2. layer of KABRIC is being applied. Apply 2. layer to the wall again, using the same method and technique. The thinner the 2. layer is, the more lifelike will the expression and finish become. Try to avoid making knobs and sharp edges.

Remove the tape before KABRIC dries and allow the wall to dry until the next day before Topcoat is applied, or shelves and pictures are to go up in the wall.