



**DETALE
CPH**

KC14

Instructions KC14 Classic & KC14 Raw

Easy to apply and pleasing to your senses. Share your story #detalecph	
---	--



Share your DETALE project

Share your DETALE project and find other inspiring projects on Instagram under #detalecph. We are happy to share your pictures & stories. Please send it to our email: hello@detalecph.com.

Follow our projects

Find us on Facebook or Instagram under DETALE CPH or visit us on www.detalecph.com. Please send all constructive feedback on hello@detalecph.com.

Hardening and durability

KC14 Classic and KC14 Raw is only fully hardened after 2-3 weeks. Be aware that the wall will never become rock hard and therefore is receptive to scratches ect. With the second layer of Topcoat you obtain a dirt repellent surface corresponding to a gloss 10 paint, meaning that the surface can be washed as instructed above. We do not recommend using KC14 Classic and KC14 Raw on backsplashes, as the surface will not be resistant towards hot splashes.

Maintenance and cleaning

KC14 Classic and KC14 Raw can be maintained by using Topcoat. 1-2% of Topcoat can be added to washing water as needed. Otherwise clean the wall using only gentle detergents.



**DETALE
CPH**

You will need

2 spatulas of 15-35 cm in size
Sandpaper grain 120-220 (look at section 2)
Shielding e.g. plastic or cardboard and masking tape
1 soft duster
Microfiber cloth for Topcoat (opt. hand sprayer)
Gloves and respiratory protection for sanding

Prepare

The surface on which KC14 is to be applied has to be smooth, dry, equally absorbent and sustainable. If in doubt, you should prime the base before beginning. It is important to carefully cover in order to avoid unwanted spots. Topcoat in unwanted spots, is very hard to remove. The process of sanding will produce dust.

1

Set up masking tape around the desired area to cover. Apply KC14 on the entire area at once. The plaster should have a thickness of 2-3 mm, with a smooth covering layer. If the layer is not smooth, plaster spots will be noticeable in the final result. Remove the masking tape before the plaster dries. The plaster has to dry for a minimum of 16 hours.

Tip: The finish depends on the way you apply the plaster. Avoid applying in straight lines, but with smooth and soft curves. Bubbles can appear and are part of the natural look.

2

If the plaster appears with irregularities or knobs, sand these away before second layer is being applied. Use sandpaper grain 180 for KC14 Classic and grain 120 for KC14 Raw. Dust off the area by using a soft duster.

Set up masking tape again and apply KC14 Classic on the entire area at once. The second layer must not be too thin as it will increase the risk of sanding through the surface and leave noticeable marks. Remove the masking tape before the plaster dries. The plaster has to dry for a minimum of 16 hours.

3

Make sure that the plaster is totally dry before you start sanding. Do also make sure to cover furniture etc. carefully given that sanding produces a lot of dust. Sand the entire area by hand and in circles for a smooth and consistent surface. Use sandpaper grain 180 for KC14 Classic and grain 120 for KC14 Raw. Again, avoid sanding through the surface as clearly noticeable marks will appear. Sanding machines cannot be used! Dust the whole area thoroughly with a soft duster. Remain all covering for the next step, as unwanted Topcoat stains are very difficult to remove.

4

Set up masking tape once again. Apply the Topcoat twice by using the microfiber cloth to dab it on with an interval of 1-2 hours. The entire area has to be coated at once. Be aware of coat-drips when applying, as they are clearly visible at the final result. Let the second layer dry for 2-3 hours before sanding the area lightly with grain 220 to achieve smoothness. Dust off the area using a damp cloth.

Tip: Hand sprayer can be used. Do only spray small areas at a time and make sure to immediately dab the area with a microfiber cloth before the Topcoat dries. A third layer can be applied if the area is exposed to much wear.