

# Quick Fixes: What can you do immediately?

- 1 Evaluate your choice of the endpoint indicator (Rhodanine vs. Potassium iodide?)
- 2 Determine your possible interferences (What metals does your ore contain?)
- 3 Revisit your sampling regime
- 4 Use reference solutions to examine your accuracy
- 5 Check your reagents

