

BATH SPOUT INSTALLATION INSTRUCTIONS

Important Information

- Not suitable for gravity feed systems.
- All pipework must be thoroughly flushed prior to installation.
- Please check the product before installation, make sure there is no visible damage.

Claim on damage after installation is not accepted.

Installation

1. Check the thread on the nipple has the correct length. Cut to length if required. Also make sure end face is square.
2. Apply Teflon tape to the thread. Care must be taken that Teflon tape cannot become dislodged and block the flow regulating device, causing a reduction in water flow.
3. Use an Allen key to unscrew a spout adapter inside of spout. Screw the adapter onto threaded nipple on the wall. Tighten it firmly using Allen key.
4. Push spout onto the spout adapter. Fasten Grub screws using the Allen key provided. Make sure the outlet is pointing downwards.
5. Turn on the water and check if there is any leak.