

WALL TOP ASSEMBLIES INSTALLATION INSTRUCTIONS

Important Information

- All pipework must be thoroughly flushed prior to installation.
- Hot and Cold water inlet pressures should be equal.
- Maximum operating pressure at any outlet is 500 kPa.
- Maximum hot water temperature is 80°C.

Installation

1. Check in-wall depth is less than 12mm. Check seats in recess tap bodies are in good condition and free of foreign materials. Reseat if required.
2. Unscrew the pin lever (8) from handle (9). Using Allen key (supplied) to loosen the grub screw inside and remove handle (9). Unscrew wall flange (4) and dress ring (3) off spindle (2). Remove locknut (1) from cartridge (2).
3. Screw cartridge (2) into tap body on the wall. Using a suitable spanner, tighten cartridge until it comes to a firm stop. Then fit locknut (1) and tighten it using a suitable spanner.
4. Screw back on dress ring (3) and wall flange (4) and tighten fully by hand against wall/tile. Please take care not to damage the decorative finish.
5. Fit handle assembly as follows:
 - Turn both spindles to the fully closed position.
 - Fit Handle (9) on the spindle, make sure H on the left, C on the right.
 - Use Allen key to tighten the grub screws inside to lock the handle in the position. Screw the pin lever (8) into the handle (9). Make sure the pin levers on hot and cold are leveled.

