

ACCESSORY INSTALLATION INSTRUCTIONS

MOUNTING KIT SUPPLIED

- Self Tapping Screw*2
- Plastic Plug *2.
- Allen Key*1

INSTALLATION INSTRUCTION

1. Use the Allen key (supplied) to remove the mounting plate from back of accessory.
2. Place the mounting plate where it is to be mounted. Mark center position of slotted holes.
3. Using a masonry drill bit to drill 2 holes marked on the wall. Press plastic plugs into the holes. For plasterboard wall use expanding toggle screws (not supplied).
4. Place mounting plate in position. Insert screws (supplied) and tighten firmly with a Phillips head screwdriver.
5. Place accessory (or accessory flange) over mounting plate and tighten grub screw firmly with an Allen key.

MAINTENANCE AND CARE

Chrome (or other colour) plated surfaces should be cleaned with mild soapy water. Do not use cream cleaners or citrus based cleaning products as they are abrasive. Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty.