



ROCKSTOP



ROCKSTOP FITTING GUIDE

1. Put the first bead onto your rim as normal.
2. Locate your valve and place any of the holes on your Rim Protector over it.
3. Feed the Rim Protector around the rim and stretch it over - it will start to get tight on the last section.
4. Once in place, ensure the notches underneath Rim Protector are sitting in the centre channel of the rim.
5. Work the already positioned bead underneath the Rim Protector, so that it is seated correctly. This also allows some slack on the tyre, ready for the second bead.
6. Put the second bead on and work it underneath Rim Protector as before,
7. Once your tyre is on, flatten the top of the tyre all the way around to ensure Rim Protector is sitting evenly in place. This also pushes the outside beads of the tyre into position ready to inflate.
8. Inflate, Lock, Shred!



WATCH FITTING VIDEO

[ROCKSTOPMTB.CO.UK/FITTING](https://rockstopmtb.co.uk/fitting)

@ROCKSTOPMTB



@ROCKSTOP_MTB



ROCKSTOPMTB.CO.UK

