




Drapery & Hardware Installation Guide

Double Return Rod Drapery

The Tools You'll Need



The Hardware We Provide



THE ROD IS IN ONE, SINGLE PIECE




Complete Step 1A, Then Proceed to Step 2.

THE ROD IS SPLICED INTO TWO OR MORE PIECES.

Complete Steps 1A & 1B, Then Proceed to Step 2.




STEP 1A: Attach Rod Backplates

Each return on the rod has a set screw for securing the post bracket backplate. You'll find the set screw on the bottom of the return rod. Slide the return onto the post bracket backplate and tighten the set screw using the provided Allen wrench. Repeat on the other side.




STEP 1B: Assemble Your Rod Pieces

The end of each rod segment has a set screw for securing the splice. You'll find the set screw on the back of each segment of the rod approximately 2" from the end of the non-return side. The splice connector is a smaller diameter piece of rod, about 8" long. Slide the splice connector halfway into one rod segment and tighten the set screw with the provided Allen wrench. Repeat on the other rod segment. Rotate the rods such that the set screws are on the back, next to the wall. *Once installed, only a thin seam remains which will be completely hidden behind the middle bracket, thus making the rod appear as a continuous, seamless rod.*




NO BRACKETS PROVIDED

Proceed to Step 3.



ONE BRACKET PROVIDED

Complete Step 2,
then proceed to Step 3.








THREE BRACKETS PROVIDED

Complete Step 2,
then proceed to Step 3.

STEP 2: Mount Center Bracket to the Wall.





Locate the horizontal center of your window and the mounting height listed on your Everhem packing slip. Tape a piece of paper up on the wall in this general area to avoid marking up the wall. Next, mark the paper at the exact spot where the center bracket will be mounted. From that spot, mark the paper with perpendicular lines. Place the bracket against the wall, aligning the top of the bracket with the horizontal line and the center of the screw holes with the vertical line. Make sure it is level, then **mark the screw holes** with a pencil. Using your power drill and the 7/64" drill bit, **drill into the marked holes**. If your drill doesn't hit a wooden stud, install one of the provided SNAPTOGGLE Toggle Bolts anchors. Please refer to [this video](#) for instructions. If your drill does hit a wooden stud, no anchor is required. Line the bracket up with the pre-drilled holes. Use the provided wood screws (machine screws if anchors were used), and a Phillips head screwdriver to **secure the bracket into place halfway**. Remove the piece of paper from behind then tighten the screws to fully secure the bracket.

Center Bracket Positioning Guide






STEP 3: Find Backplate Mounting Position.

Moving away from the left outside edge of your window, locate the intersection of the following points: (1) Left Stack Width and (2) Mounting Height listed on your Everhem packing slip. **Tape a piece of paper up** on the wall in this general area to avoid marking up the wall. Next, mark the paper at the exact spot where the mounting plate will be positioned. From that spot, mark the paper with perpendicular lines. Repeat this process on the right side of your window. With the rod held firmly against the wall [or resting on the mounted bracket, align the top of each mounting plate with the horizontal line and the outer edge of each mounting plate with the vertical line. Make sure the rod is level, then **mark the screw holes** with a pencil. Using your power drill and the 7/64" drill bit, **drill into the marked holes**. If your drill doesn't hit a wooden stud, install one of the provided SNAPTOGGLE Toggle Bolts. Please refer to [this video](#) for instructions. **Push the rod into the predrilled hole using a Phillips head screwdriver**. If your drill does hit a wooden stud, no anchor is required.




STEP 4: Add Rings to Rod.

To add your rings, first count how many hooks are on your drapery panels. Identify the ring type for the rod - bypass or regular - listed on your Everhem packing slip. Loosen the set screw on one post bracket and remove from the rod, then place as many rings on the rod as the hooks on your drapery panels, then reattach the post bracket by tightening the set screws. *Please Note: If using Bypass rings, make sure the opening of the "C" is facing the wall and the eyelet underneath the ring is at the bottom.* ***Please note, if your primary and secondary rod differ in diameter, use the larger set of rings.*



STEP 5: Secure Primary Rod to the Wall.


If you installed a center bracket, first divide the rings - bypass or regular - evenly between each side. Otherwise, proceed to securing the rod to the wall. Line each mounting backplate up with the pre-drilled holes. Use the provided mounting screws, your power drill and your Phillips head socket bit (or Phillips screwdriver) to secure each mounting backplate into place halfway. Remove the piece of paper from behind then tighten each mounting backplate fully to secure the rod.



STEP 6: Assemble Secondary Rod and Add Rings

If your rod is in more than one piece, the end of each rod segment has a set screw for securing the splice. You'll find the set screw on the back of the rod approximately 2" from the end. The splice connector is a smaller diameter piece of rod, about 8" long. Slide the splice connector halfway into one rod segment and tighten the set screw. Repeat on the other rod segment. Rotate the rods such that the set screws are on the back, next to the wall. *Once installed, only a thin seam remains which will be completely hidden behind the middle bracket, thus making the rod appear as a continuous, seamless rod.* If your rod is in one piece, proceed to adding your rings. To add your rings, first count how many hooks are on your drapery panels. Identify the ring type for the rod - bypass or regular - listed on your Everhem packing slip.

**Please Note: If using Bypass rings, make sure the opening of the "C" is facing the wall and the eyelet underneath the ring is at the bottom.*
***Please Note: If your primary and secondary rod differ in diameter, use the smaller set of rings. Otherwise, all rings will be the same size.*





NO BRACKETS PROVIDED

Complete Step 7A,
then proceed to Step 8.



ONE BRACKET PROVIDED

Complete Step 7A,
then proceed to Step 8.




THREE BRACKETS PROVIDED

Complete Steps 7A and 7B,
then proceed to Step 6.





STEP 7A: Secure Secondary Rod

If you installed a center bracket, first divide the rings - bypass or regular - evenly between each side. Otherwise, proceed to securing your secondary rod. Locate the sleeves at each end of the Secondary Rod and the backplate inside the return of the Primary Rod. Slide the sleeve over the end of the Secondary Rod. Hold the end of the rod (with sleeve) up to the backplate and slide the sleeve over the backplate. Position the set screws facing up (on top, facing ceiling) then tighten the set screw to secure the sleeve to the backplate. Repeat with the other end of the rod. Adjust / rotate the rod as desired, then tighten the remaining set screws to fully secure the rod.






STEP 7B: Mount Support Brackets to the Wall.

If your rod has two additional support brackets, these will be bypass brackets that enable the rings to pass by them when opening and closing the drapery panels. Each of these brackets should be placed halfway between the end and center of your rod. If your rod is spliced into multiple pieces, make sure to place a bracket at the seam where the splices are located. Place the first bracket up on the wall with the cup resting under the rod centered horizontally around one of the seams. Making sure the bracket is level, mark the screw holes with a pencil. Using your power drill and the 7/64" drill bit, drill into the marked holes. If your drill doesn't hit a wooden stud, install one of the provided SNAPTOGGLE toggle bolts. If your drill does hit a wooden stud, no anchor is required. Line each bracket up with the pre-drilled holes. Use the provided mounting screws, your power drill and your Phillips head socket bit (or Phillips screwdriver) to secure the bracket fully into place. Repeat on the other side with the remaining bracket.






STEP 8: Install Sheers Panels and Wands onto Secondary Rod

From the furthest left ring, place the furthest left hook of your sheers panel through the eyelet of the ring until the panel is fully secured. Repeat for additional panel(s). For a pair of sheers panels, hang one wand on the eyelet of each center most ring. For a single sheers panel, hang one wand on the eyelet of the farthest left or right ring.



STEP 9: Install Drapery Panels and Wands onto Primary Rod

From the furthest left ring, place the furthest left hook of your drapery panel through the eyelet of the ring until the panel is fully secured. Repeat for additional panel(s). For a pair of drapery panels, hang one wand on the eyelet of each center most ring. For a single drapery panel, hang one wand on the eyelet of the farthest left or right ring.



Cleaning Instructions

Drapery & Roman Shades

Deep Cleaning is recommended every six months. Between deep cleanings, we recommend maintaining your products using a vacuum with a hose attachment.

Woven Woods

Woven woods are very delicate and can be cleaned by carefully using a vacuum with a hose attachment.

Drapery Hardware


Clean your Everhem hardware with a chamois cloth and a little warm water.

Warranty & Returns

Due to the incredibly nuanced and custom nature of window coverings, all items are considered final sale and we are unable to accept returns.

Everhem Drapery, Roman Shades, Woven Woods and Hardware are all custom made by hand in the United States; our products contain intricate components that should be handled with care. If your product arrives damaged or defective, please contact hello@everhem.com within 48 hours of receiving your order so we can troubleshoot the issue and help with replacement, repair or other resolution. Proof of damage or defect will be required and is subject to review by our team.

If your product arrives incorrect due to customer error, we are not responsible for the product replacement or repair. However, it is always our aim to make things right. Please contact us at hello@everhem.com, our team is happy to assist you with a prompt resolution.



Follow us and share
your Everhem products! 



@everhem



everhem



More questions? Reach out to us.
We're happy to help! 



hello@everhem.com

Thanks for your order!
Come visit us again sometime. 



[everhem.com](https://www.everhem.com)

