



Version 1.8 Default Diagnostic, 5/21/12

## DEFAULT HARD RESET

1. Un-plug and re-plug in Power Cord to verify software version 1.8, which shows on the part of the display where surface temperature is usually found. Must be version 1.8
2. Turn display off
3. Hold SET button then press POWER button and release to turn display on.
4. Press SET button 8 times until defaults screen appears. Default screen shows two-digits in all four locations with no decimal points. The amount you are away from the default for each value will show here.
5. Hold SET button until the decimal points flash 10 times. This restores the factory defaults. Press POWER button to save.
6. Now you can start the calibration process over as per the Owner's Manual if desired.