

therM[®] hub

Want more information?

Here to help - call us now on
0333 800 1750

www.ufh.co.uk/therm
technical@ufh.co.uk
info@ufh.co.uk



therM is a registered Trademark of Plumb Partners Group Ltd. All rights reserved.
Specification is subject to change. E & OE.

? Setting up therM hub

therM hub is designed to be quick and simple to setup.

Just follow the quick start set up sequence and you will soon have total control over your home heating system.


? System requirements

- An active broadband connection.
- 230v mains supply (Adaptor supplied).
- A broadband router with DHCP function.
- A mobile device running iOS, Android or Windows Operating System.



1. Connect power

Connect the power supply to the therM hub. Connect the therM hub to the router with the Ethernet cable provided – the router will assign an IP address to the therM hub.




2. Download application

Connect your mobile device to the same wifi network as your therM hub. Download the FREE therM app from the Apple App Store, Google Play Store and register an account.



3. Add location

Once registered, select the add location option and follow the instructions.



4. Connect to therM hub

Press the connect button on the therM hub to add the Location to your Account.




5. Name your therM hub

When successfully connected, add a title for the new location (e.g. Home) and configure the time zone for the system.



6. Add zone

The next step is to join therM stats to the therM hub. Select Add Zone in the therM app.




7. Assign a zone name

You should now enter the name for this new zone and then press Add Zone.




8. Pair your therM stat

On the therM stat, use the Left / Right keys to select SETUP and press Tick<>✓
Feature 01 is displayed on screen.



9. Pair your therM stat

Press the Tick key to pair the therM stat to the therM hub✓
The MESH symbol appears flashing on the display.
When the therM stat successfully connects to the therM hub the MESH symbol will then be permanently displayed.



10. Add another zone

When complete, press Next and repeat these steps for all additional zones on the network.



11. Complete setup

When all zones have been added, press Finish on the app to complete setup.

