


# FLEXCELL<sup>®</sup> HT CELL SEEDERS

- Cell seeders allow users to plate cells in the central region of the culture plate helping to prevent cells from being subjected to undefined strains when using loading stations.
- Used during plating of cells in HT BioFlex<sup>®</sup> plates only and not during application of equibiaxial strain.
- Sold individually or as part of a baseplate kit.



**Figure 25.** 24-well cell seeder well illustrating where cells will be plated.



## Baseplate Kit includes:

- Baseplate
- 4 Gaskets
- Corresponding Loading Stations
- 4 Cell Seeders
- 4 Sample Plates
- Acrylic Window
- Grease
- Software update, if needed

### ORDERING INFORMATION (Please contact distributor for pricing)

Catalog Number	Product/Item	Price
HTCS-3000	HT Cell Seeders (Set of 4)	
HTBK-4000	24-well HT Baseplate Kit	