



English:

Setting up air-Q without Smartphone-App

1. Connect the air-Q with the included USB-C cable and the power supply. The device will boot. Both LED strips (green and blue) will indicate the booting process. This lasts approximately 15 to 20 seconds. An air-Q Wi-Fi hotspot can now be found. Connect to this hotspot (Please ignore / accept information about a non-existent internet connection):

```
SSID:      air-Q - Device [abcde]  
Password:  airqsetup
```

(abcde stands for the first five characters of the serial number as an example of the device > see device sticker)

2. Open in browser the website

```
http://192.168.4.1  oder  http://air-q.local
```

3. Integrate the air-Q into the WLAN available at the place of residence / work. Attention: Only 2.4 Ghz networks are recognized.
4. Assign the name and type of room to the air-Q. The type of room influences the type of evaluation of the measurement data!
5. Assign a new password for the air-Q and press "SAVE".

Settings reset (All settings (Wi-Fi, individual settings of the device will be deleted):

Press and hold the reset button for approximately 5 seconds. The LEDs indicate the progress in white and will all turn green once the process has been successfully completed.

Factory reset (All settings and data will be irrevocably deleted):

Press and hold the reset button for approximately 15 seconds (longer than the settings reset). The LEDs indicate the progress in orange and will all turn green once the process has been successfully completed.