

Charging the Teleport

Teleport has two methods of charging its batteries. Please note: Teleport must be switched ON during charging. The LED colour guide provides more information on the Teleport's battery status (see LED Colour Guide).

Method 1 (via Charging Mat - see Accessories)

1. Plug power supply into charging mat. Plug the other end of the power supply into the wall socket.
2. Drive Teleport over the mat and have the charging terminal strips make contact with the charging contact pins. Please note: after driving onto the mat, Teleport will slow down to a safe speed for docking.



Method 2 (via Power Supply)

1. Connect the power supply to a wall socket and directly plug the DC head into Teleport, as shown.

