

MA-405 Scale Calibration Guide

Prior to calibrating the scale, clean or dust off any grain that is inside the device and make sure that the device is sitting on a flat level surface. When calibrating the scale, the dump cell is not needed. Make sure there is nothing on top or inside the device.

A quick video tutorial of this process can be found here: <https://youtu.be/oqejdisjCT8>

Calibrating the Scale

1. Go to Settings > Scale > Calibrate Scale.
2. Make sure that the device is empty and press Start to set the zero of the scale.
3. Gently place the 200 gram weight in the grain tube beside the cone and press Start.



4. The device will go back to the Scale Settings once calibration is complete.

Checking the Scale

1. Go to Settings > Scale > Check Scale.
2. When the device is **empty**, the scale should read **0g**.
3. Place the 200 gram weight in the grain tube. The scale should read **200g**. +/- 1 gram is acceptable.
4. If your device does not do so, please re-calibrate the scale.

Contact Us

Once again, a video tutorial of this process can be found here:

<https://youtu.be/oqejdisjCT8>

If you are experiencing any difficulties, call Mehrdad at +1 204-962-3500 or email technical support at technical@grainanalyzers.ca.