


800/1100 SHOWER CHANNEL



SPECIFICATIONS



CLEANING & MAINTENANCE:

Shower Channels should be cleaned with mild detergent and water
All Products must be cleaned with a soft cloth with soapy water, avoid
waxes, solvents, abrasives, acids and other chemical based cleaners
Warranty will be void if damages are caused by unsuitable cleaning
products

WARRANTY INFORMATION:

1 Year Parts or Products Replacement Warranty
All products have a full 1 year in house labour warranty from date of
purchase