

Continue



## **Sonos connect instruction manual**

**Sonos connect instructions. Connect sonos. How to connect app to sonos. Sonos connect amp instructions. Sonos 5 instructions. Sonos installation instructions. Sonos connect gen 1 manual. Sonos connect manual pdf.**

To begin using your Sonos Connect:Amp, locate a suitable spot and plug it into power. Then download and install the Sonos app on either your iOS or Android device. Follow the in-app instructions to set up your Connect:Amp. If you have an older model of the device, use the Sonos S1 Controller app for setup. Ensure the speaker wire gauge is between 12-16 for optimal sound quality and follow specific guidelines for connecting multiple speakers. To get started with your Sonos Connect, download the Sonos app on either iOS or Android. Within the app, navigate to 'Add Speaker or Component' - if using the S1 Controller, select 'Continue > Set up products'. Follow the prompts to set up your Connect and connect your content services. If you're adding an existing system, go to the Settings menu in the Sonos app, select 'Add Speaker or Component', and then follow the on-screen instructions. The Connect has RCA inputs for connecting devices like turntables or CD players - simply plug the cable into the correct inputs. When outputting audio, ensure your amplifier or receiver is set to the correct input; if you're experiencing issues, refer to our article on troubleshooting no sound from Connect. For digital audio, connect a coax cable or TOSLINK optical cable from the Connect's outputs to your amplifier or receiver's corresponding inputs. To adjust volume control, open the Sonos app, navigate to Settings, select the room with your Connect, and choose Line-Out Levels. Set it to Fixed for exclusive volume control on your amplifier or receiver, or Variable for in-app volume adjustment. If you need further assistance, reach out to our technicians via phone or live chat, or consult our Sonos Community for support from other users.