| | Spray and Circulate | |
|---|---|---|
| safetraces | Prepared by: M. Clark | Program: Training |
| | Document Number: TRN-80106-003 | Number of Pages: 1 |
| | Effective Date: December 2021 | Version: 3 |

1. **veriDART® Best Practices**
    a. Origin Point Verification
        i. Set-up, label accuracy and air sampler are operational and functional
        ii. Tag Accuracy

    b. Release Location
        i. Try not to release under Supply and Returns
        ii. Release "with" the wind

    c. Release Verification
        i. After each Tag release, leave the Tag and used gloves at the release location

    d. Bucko Purge
        i. To ensure uniform spray, purge the release sprayers prior to the first release at each Origin Point

2. **Standard Release Instructions for Manual Sprayers**
    a. Record start time
    b. Wear new and clean gloves for each Tag release
    c. Release three to five feet from the ground and about six feet from the nearest Air Pump. (Setting/Standing Levels)
    d. At each Origin Point release 10-12 ml of Tag. This can be done by squeezing the Bucko Release Trigger 10 complete and consecutive times

3. **Tag Release Volume**
    a. 1.2 ml/spray
    b. 10 Continuous Sprays
    c. Total Spray Volume: 10 - 12 ml

4. **Circulation Interval**
    a. Allow the full test interval time for sample collection
    b. Once all releases have been completed you must stay in your assigned zone until time to sample
    c. Leaving your release zone and entering a different release zone increases the chance for cross-contamination

**"Confidential property of SafeTraces, Inc.,**
**do not copy or distribute without prior written consent from SafeTraces, Inc."**