



REKOLA

Rekola Reflex pads for DuoFlex



Product code	Color code	Dimension	
11-90076	Blue	23 x 19 cm	Rekola Reflex glass cloth pad for DuoFlex, 28 grs
11-90077	Blue	23 x 19 cm	Rekola Reflex AbrasiveSoft pad for DuoFlex, 30 grs
11-90080	Blue	23 x 19 cm	Rekola Reflex mesh cloth pad for DuoFlex, 28 grs
Packed	5 pcs pp bag		40 pcs 5-pack per transport box
Where:	Hard top , ceramic and chrome and glass surfaces for hygienic cleaning results: e.g. toilet bath and sink facilities at healthcare, nursery, school, university, office, public building, hospitality and residential. Surfaces at sport facilities, food industry, locker rooms, etc, as replacement for microfiber hand cloths.		
How:	<p>In conjunction with Rekola Reflex DuoFlex hand tool, apply the Velcro loop side to the hooked surface of the hand tool.</p> <p>Squirt a few drops of desired liquid onto the pad with sprinkler, or if spray flacon in use, apply a few squirts of liquid onto the surface and use dry pad.</p> <p>Due health reasons, we advise adapting nozzles of spray flacons to jet position.</p> <p>Alternatively charge pads in a washing machine, by adapting the spin cycle of the final rinse.</p> <p>Avoid overdosing, bleach and softeners</p>		
Charge:	<p>With clean water; optional diluted with UMF suitable chemical according to manufacturer's instructions.</p> <p><i>Please be aware that some chemicals may cause damage to user, material and environment.</i></p> <p>Depending on surface circumstances, charge the pads with 5-10 ml per pad.</p> <p>Regardless of the charging liquid: avoid overdosing.</p>		

REKOLA

Maintenance	
Laundry:	
Washing:	Rinse twice to ensure all cleaning chemicals are removed. Main program for synthetic fibers at 95°C, for environmental reasons at 60° C or less is preferred. Rinse twice to ensure all laundry agents are removed. Adjust temperatures and water volumes accordingly.
	Tumble dry at low heat.
	Do not use of bleach or softener.
	Low water level during processing or overloading washing machine (max 80% of door window) may cause irreversible damage to hand pads.
Disinfection:	Non -bleach disinfectant* laundry agent and autoclaving may be used if required *e.g. peroxide based; this may affect colors.
Durability:	500 washing cycles. Rough abrasive surfaces and intensive rubbing of open structures like drains may reduce lifetime expectations.
Disposable:	Rekola Reflex AbrasiveSoft hand pads are purely synthetic: may be used for recycling programs; or because of their high energy value and with no emissions other than CO ₂ and water can be safely disposed by controlled energy-supply programs.
Components	
Body:	
11-90076	100 Ultra Microfiber, F= 0,154 Dtex, 80% PES 20% PA. Backside knitted PES Velcro.
11-90077	50% split Ultra Microfiber, F= 0,154 Dtex and 50 % PET film 90% PES 10% PA Backside knitted PES Velcro.
11-90080	100 Ultra Microfiber F= 0,154 Dtex, 80% PES 20% PA. Mesh structure. Backside knitted PES Velcro.
Borders:	100% PES.
Characteristics	
Shrinkage:	< 6% at recommended washing instructions.
Guarantee	
500 times use and wash in general hygiene cleaning circumstances at a maintained non-safety sealed floor. Extended usage can be achieved if optimal laundry and cleaning conditions are considered. For instruction and details ask your distributor.	