

General Safety

Hazards & Restrictions

1. Small children, infants and pets should be supervised when near Teleport.
2. Do not apply a forced weight to any part of Teleport
3. Do not attempt to disassemble or damage Teleport. Should the product be disassembled or damaged in any way by the user, all warranties will be voided.
4. Refrain from inserting any metallic objects into the unit to prevent the event of an electric shock, short circuit, possible leaking of harmful substances and personal injuries
5. Avoid the handling of any liquids or chemicals within close proximity to Teleport.
6. Teleport is not designed for use on rough or uneven terrain.
7. The Teleport weighs 17kg. Ensure caution is taken when carrying Teleport.
8. Clean with a soft, dry cloth. Do not pour or spray water onto Teleport.
9. Do not store Teleport in wet or humid areas.

Charging Safety

1. Connect the dock to a standard outlet only.
2. Use only the charger supplied by the manufacturer.
3. Do not use a charger with a damaged cord or plug.
4. Do not attempt to charge Teleport if the contact terminal, power supply or charger mat is damaged.
5. Charge Teleport indoors only.
6. Never handle chargers with wet hands.
7. Always disconnect Teleport from the charger mat or power supply before cleaning.



Operation

1. Teleport is not designed to travel up or down stairs, escalators or over curbs. Always use an elevator. Use care that Teleport and Teleport accessories do not become caught in elevator doors.
2. Drive with caution when attempting to negotiate any incline.
3. Do not attempt to open any kind of door (including elevators) using your Teleport.

Electrical Safety & EMC Compliance

FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CE

Teleport complies with the essential requirements of the following EU Directives:

2014/30/EU	EMC Directive
2014/35/EU	Low Voltage Directive

RCM

Teleport complies with the EMC regulatory requirements for EMC set down by ACMA (Australian Communications Media Authority).