

# Tool Box Talk: Half-face mask inspection and maintenance



Items on the picture contained in the box when issued new. Items include:

- Sundström SR100 Mask with components.
- Instruction book.
- Storage bag with a seal.
- 1 x sterile wipe.
- 1 x name tag.
- 1 x pre filter holder.

**Disclaimer: Filter issued separately based on task. (P3 Particle filter and/or charcoal filter)**



Picture on left showing pre-filter and pre-filter holder.

Picture on right showing P3 particle filter.



Picture on the left showing the head-straps being removed from the mask.

Picture on the right showing the head-straps ready for inspection. That way defects can be seen.



Remove exhalation membrane prior to removal of holders/ casings from the mask body (**Follow steps 1 to 4 in order**)



Exhalation membrane holder with exhalation membrane and protective cap assembled.



Exhalation membrane holder with the exhalation membrane and protective cap opened and taken apart.