

Proudly flex your Flex in any configuration you desire.

Flex can be customized to fit any oil window shape you specify: square, rectangle, circle, ellipse, or even a star.

Its minimalistic design further enables a wide variety of sophisticated surface finishes that will allow your brand's flair to be the star of the show.







One Size, Two Volumes*

Flex was designed with the flexibility to house 0.5ml or 1ml of oil without altering the size or shape of the external hardware. This allows oil brands to expand their product range in a flash and utilize the same packaging for both available sizes.

"The internal structure of both sizes is different; tank volume must be defined during order placement.



Clog-Free, Worry-Free

Flex is the ideal disposable for anyone looking for a dependable and hasslefree vaping experience. Built with CCELL's cutting-edge dual air vent design, Flex ensures effortless, smooth draws with no clogs and consistent vapor delivery every time.





Specs

- Tank Volume: 0.5ml / 1ml
- Dimensions: 109.3H/110.2H x 22W x 10.5D (mm)
- Customizable oil window and mouthpiece shape

4.3H/4.34H x 0.87W x 0.41D (in)


- 0.5ml option available at the same size
- · Clog-free dual air vents
- · USB-C charging
- · Food-grade mouthpiece
- Medical-grade stainless steel center post



OEM Capabilities









Mouthpiece

Available Shapes:

OEM Option: Injection molding

Battery Case

OEM Options:

Injection molding, matte rubber oil, metallic paint, digital printing, silkscreen, laser engraving OEM Dimensions:

88.5H x 22W (mm) / 3.48H x 0.87W (in)

Highly customizable shapes. The sky is the limit!

Available Shapes:

Oil Window











OEM Capabilities









Mouthpiece

22mm

Mouthpiece

Available Shapes: **OEM Option:** Injection molding

Battery Case

OEM Options:

Injection molding, matte rubber oil, metallic paint, digital printing, silkscreen, laser engraving OFM Dimensions:

88.5H x 22W (mm) / 3.48H x 0.87W (in)

Oil Window

Highly customizable shapes. The sky is the limit!

Available Shapes:







Filling and Assembly Instructions





STEP 1

Place the preloaded battery tray onto the baseboard.



STEP 3

Fill oil into the reservoirs.



STEP 2

Put the deflector over the tray.



STEP 4

Place the preloaded mouthpiece tray onto the deflector.



STEP 5

Press with machine to seal off the filled devices.









