







CHAINGUARD

📄 | FITTING GUIDE



01	PREPARE CHAINGUARD & STRAPS	TABS
	Open the pack – ensure all Ziggy Wraps and tabs are positioned through the slots in the sides of the Chainguard. If any have come loose, work the T-bar back through the slot.	
02	CHECK ZIGGY WRAP POSITIONING	<p>💡 TOP TIP</p> <p>Leave as much excess on the Ziggy Wrap as you're comfortable with. If Chainguard requires cleaning, feed each Ziggy Wrap back through the tab, with a left-to-right motion. If you've cut the Ziggy Wrap short, it is still possible (but fiddly) to get it back in again, you may need to rethread with pliers.</p>
	Make sure all the Ziggy Wrap T-bars and tabs are lying flush with the internal surface of the Chainguard.	
03	PLACE CHAINGUARD ON CHAINSTAY	<p>💡 TOP TIP</p> <p>If you have a shallower chainstay at the back (e.g. 15mm deep), then use the tab's slot ② or ③, to thread the Ziggy Wrap through. This supports a closer fit.</p>
	Place the Chainguard on the chainstay, making sure that none of the T-bar ends are buckled and they lie flat on the chainstay. The embossed mountain logo on top of the chainguard should be pointing towards the front of your bike and the Ziggy Wraps should be on the outside of the chainstay.	
04	SECURE CHAINGUARD WITH WRAPS	<p>💡 TOP TIP</p> <p>Whilst it is possible to install Chainguard with your wheel attached, removing it before fitting will make the process easier.</p>
	Thread the ends of the Ziggy Wraps through the slot ① on the tab. Gripping the end of the tab with your thumb and forefinger, gently but firmly pull the Ziggy Wrap <i>upwards</i> through the slot, until the Chainguard is properly secured on the chainstay. Don't over tighten – Ziggy Wraps are designed to stretch and hold the chainstay, but aren't designed as cable ties.	
05	SNIP EXCESS MATERIAL	<p>💡 TOP TIP</p> <p>Tighten the straps firmly enough so that Chainguard doesn't swivel or slide along the chainstay.</p>
	Once you're happy with the fit, snip off the excess from the Ziggy Wraps, leaving at least 2 Zigs after the slot. See more in our 👉 Top Tips .	