




DuraSAFE Series

Transition into Loose Fill over Aggregate



LEGEND:

- ① Engineered Wood Fiber or Approved Alternate Loose Fill Surface.
- ② Continuous Bead of DuraSAFE tiles Adhesive at Each KrosLOCK® Joint.
- ③ DuraSAFE tiles (See Specifications for Thickness and Color).
- ④ Apply Adhesive to Entire Base Surface Prior to installing Tiles With a 3/8 Notched Trowel (on sloped area only).
- ⑤ Compacted Aggregate Base at a rounded 20 degrees slope. Run ties down the slope and beyond. Do not bend on seam.
- ⑥ Minimum 1" Fines
- ⑦ Minimum 4" Granular A
- ⑧ Tiles to be Secured with Weight at Transition Unit Adhesive Cures – Min. 24Hrs.

NOTES:

1. Consult with a local Civil Engineer to find out what drainage system is best for your application.
2. Ensure subsoil drains towards drainage system.
3. Review Most Recent Installation Manual and Sub Surface Guide

DuraSAFE Thickness	Critical Fall Height (FT)	FILE NAME	Transition to Loose Fill	PREPARED BY	B. GOSS
2.00"	3'	REV	DESCRIPTION	DATE	
2.25"	4'	0	ORIGINAL ISSUE	08/16/2016	
2.75"	5'				
3.25"	6'				
3.75"	7'				
4.25"	8'				
4.75"	9'	SIZE	SCALE	DWG NO.	REV
5.00"	10'	A	N/A	2017-026	1
5.25"	12'				



4393 DISCOVERY LINE
 PETROLIA, ONTARIO
 NON TRO
 PHONE: (800) 263-2363
 PHONE: (519) 882-8799
 FAX: (519) 882-2697
 EMAIL: info@softsurfaces.com