


SIMPLFIT KITSET INSTALLATION INSTRUCTION

NOTE: THESE INSTRUCTIONS ARE BASED ON A 2100MM HIGH TOP SHELF DESIGN.


STEP 1: MARKING THE POSITION OF THE WALL BRACKET



- Use a pencil mark on the wall at a height of 1750mm from the floor. This mark represents the bottom edge of the wall bracket.
- Transfer the 1750mm mark along the wall using a level.




TIP: If your level is short, you can place the level on the wall bracket and use the wall bracket as a straight edge.

STEP 2: LOCATING AND MARKING THE WALL STUD POSITIONS




- Locate the timber studs in the wall, either by using an electronic stud finder or simply by knocking on the wall.
- Mark the position of the studs on the wall just above the 1750mm height mark.
- The stud position can be checked by drilling small test holes into the wall. The test holes should be drilled where they will be later concealed by the wall bracket.

STEP 3: PREPARING THE WALL BRACKET FOR INSTALLATION.



- Place the wall bracket against the wall in the correct position. ENSURING that the wall bracket is the RIGHT WAY UP and in its intended location.
- Mark the centre position of the wall studs onto the wall bracket.
- Drill two countersunk holes through the wall bracket at the stud centre positions (Refer to the diagrams above).


STEP 4: INSTALLING THE WALL BRACKET.



- Hold the wall bracket in the marked position on the wall and firmly drive in the long screws provided into every hole.
- Your Simplfit wall bracket should now be in place and ready to hold the melamine components!

IMPORTANT: In situations where you are fixing to wall with extra layers of wall lining (e.g sound proof wall) longer screws will be required.

STEP 5: PLACING THE VERTICAL PANELS ON TO THE WALL BRACKET.



- Hang the vertical panels in the approximate position as per the wardrobe organiser design.