



## Introduction

Sample preparation is one of the essential steps of bottom-up proteomics. The PreOmics iST sample preparation kit is designed to assist researchers achieving best results with few sample preparation steps and little hands-on time. For sample-specific protocols and optimization visit [www.preomics.com/downloads](http://www.preomics.com/downloads) or contact [info@preomics.com](mailto:info@preomics.com).

## Kit Contents

The iST-NHS kit provides a streamlined solution for reliable sample preparation compatible with chemical labeling. It includes all chemicals to denature, reduce and alkylate proteins, as well as the enzymes to perform a tryptic digestion and a final peptide cleanup.

Component	Cap	Quantity	Buffer Properties				Description	Storage
			Organic	Acidic	Basic	Volatile		
DIGEST	●	3x					Trypsin/LysC mix to digest proteins.	-20°C
RESUSPEND	●	1x 2 mL				●	Reconstitutes lyophilized proteolytic enzymes.	RT
LYSE-NHS	●	1x 2 mL			●		Denatures, reduces and alkylates proteins.	RT
STOP	●	2x 1 mL	●	●		●	Stops the enzymatic activity.	RT
WASH 1	●	2x 2 mL	●	●		●	Cleans up peptides from hydrophobic contaminant.	RT
WASH 2	●	2x 2 mL		●		●	Cleans up peptides from hydrophilic contaminants.	RT
ELUTE	●	2x 2 mL	●		●	●	Elutes the peptides from the cartridge.	RT
LC-LOAD	○	2x 1 mL		●		●	Loads peptides on reversed-phase LC-MS column.	RT
CARTRIDGES		12x					Cartridge for 1 to 100 µg protein starting material.	RT
WASTE		12x					2.0 mL tube for collecting waste after washing steps.	RT
COLLECTION		12x					1.5 mL tube for collecting peptides after elution.	RT
ADAPTER		12x					Enables a cartridge to be placed into a tube.	RT

## Pre-Requisites

Common lab equipment is required for the sample preparation.

Equipment	Quantity and Description
PIPETTE	Careful sample handling and pipetting reduces contaminations and improves quantification.
SAMPLE	Pelleted cells or precipitated protein. For other sample types contact PreOmics for adapted protocols.
HEATING BLOCK	Two heating blocks are recommended to support protein denaturation and digestion.
CENTRIFUGE	1.5/2.0 mL reaction tube centrifuges are required for loading, washing and elution.
SONICATOR	If the sample contains DNA, shear it by sonication (e.g. Diagenode Bioruptor®).
VACUUM EVAPORATOR	Vacuum manifolds evaporate volatile buffers from the eluate before LC-MS.
ULTRASONIC BATH	Optional: can be used to resuspend peptides.
LABELING REAGENT	Labeling reagent (e.g. 400 µg labeling reagent in 41 µL dry acetonitrile for 100 µg peptides).
LABELING BUFFER	Anhydrous acetonitrile & quenching buffer (5% hydroxylamine), as recommended by the manufacturer.



## Method

### 1 LYSE

- 1.1. Add 50  $\mu\text{L}$  **LYSE-NHS** (orange circle) to 1-100  $\mu\text{g}$  of protein sample, place it in a HEATING BLOCK (95°C; 1,000 rpm; 10 min). **\*NOTE1\***
- 1.2. Optional: Spin down droplets (RT; max. 300 rcf; 10 sec).
- 1.3. If the sample contains DNA, shear it in a SONICATOR (10 cycles; 30 sec ON/OFF). Let sample cool down to RT.

### 2. DIGEST

- 2.1. Add 210  $\mu\text{L}$  **RESUSPEND** (yellow circle) to **DIGEST** (red circle) (1 tube for 4 reactions), shake (RT; 500 rpm; 10 min), pipette up/down.
- 2.2. Add 50  $\mu\text{L}$  **DIGEST** (red circle) to sample and place it in a pre-heated HEATING BLOCK (37°C; 500 rpm; 1-3 hours).

### 3. LABEL

- 3.1. Resuspend LABELING REAGENT in anhydrous acetonitrile (e.g. 4:1 ratio of label:peptides).
- 3.2. Add resuspended LABELING REAGENT to sample, pipette up/down, incubate shaking (RT; 500 rpm; 1 hour).
- 3.3. Add 10  $\mu\text{L}$  QUENCHING BUFFER (5% hydroxylamine) to sample, pipette up/down.
- 3.4. Add 100  $\mu\text{L}$  **STOP** (black circle) to sample (precipitation may occur), shake (RT; 500 rpm; 1 min), pipette up/down. **\*SP\***

### 4. PURIFY

- 4.1. Use **ADAPTER** to place **CARTRIDGE** in **WASTE** tube. Label all tubes.
- 4.2. Transfer sample to **CARTRIDGE**. Be careful not to damage the bottom layer of **CARTRIDGE**.
- 4.3. Spin **CARTRIDGE** in a CENTRIFUGE (3,800 rcf; 1-3 min). If needed, adjust time to ensure complete flow-through.
- 4.4. Add 200  $\mu\text{L}$  **WASH 1** (blue circle) to **CARTRIDGE**, repeat step 4.3.
- 4.5. Add 200  $\mu\text{L}$  **WASH 2** (green circle) to **CARTRIDGE**, repeat step 4.3. **\*SP\***
- 4.6. Use **ADAPTER** to place **CARTRIDGE** in a fresh **COLLECTION** tube. Label all tubes.
- 4.7. Add 100  $\mu\text{L}$  **ELUTE** (pink circle) to **CARTRIDGE**, repeat step 4.3., keep flow-through in **COLLECTION** tube.
- 4.8. Repeat step 4.7., keep flow-through in the same **COLLECTION** tube.
- 4.9. Discard **CARTRIDGE** and place **COLLECTION** tube in a vacuum evaporator (45°C; until completely dry).
- 4.10. Add **LC-LOAD** (white circle) to **COLLECTION** tube. Aim for 1 g/L concentration (e.g. 100  $\mu\text{L}$  to 100  $\mu\text{g}$  protein starting material).
- 4.11. Sonicate **COLLECTION** tube in an ULTRASONIC BATH (5 min) or shake (RT; 500 rpm; 5 min). **\*SP\***

**\*NOTE1\*** Volumes of buffers can be adjusted according to protein starting amounts.  
Lysis temperature should be between 60-95°C.

Visit our FAQ website for more information and optimized procedures for chemical labeling: [www.preomics.com/faq](http://www.preomics.com/faq).

**\*SP\*** -

**Storage Point:** At this point, close the peptide containing tube or **CARTRIDGE** using the silicon lid.  
Peptides can be frozen at -20°C. Storage of peptides should not exceed two weeks at -20°C.  
For extended storage, finish the protocol and store at -80°C.

Please refer to [www.preomics.com](http://www.preomics.com) for our General Terms and Conditions.