

HEAD OFFICE: 37 Paramount Blvd. Derrimut Vic 3026 ABN: 70 095 343 123

Tel: 03 8390 6300 Fax: 03 8390 6366

EMAIL: ectglo@bigpond.net.au Website: www.ectglobal.com.au

WALL BASIN/BATH SET INSTALLATION INSTRUCTIONS

Important Information

- All pipework must be thoroughly flushed prior to installation.
- Hot and Cold water inlet pressures should be equal.
- Maximum operating pressure at any outlet is 500 kPa.
- Maximum hot water temperature is 80°C.

Installation

- 1. Fix mixer body onto a suitable mounting plate or noggin in the wall and secure using screws through the holes in its base. When facing the mixer, the connections should be as follows:
- Hot water inlet connection "H" below mixer cartridge.
- Cold water inlet connection "C' to the right of mixer cartridge.
- Mixed water outlet connection, to the left of mixer cartridge.
- Check all connections for leaks and the tap for correct operation.
- Mixer body must be installed square to wall/tile face and horizontal to ensure cover plate aligns with finished tile joints.
- To avoid damaging the decorative finish, do not remove the plastic sleeve until installation has been completed.
- 2. Fit the cover plate onto the mixer body (after the tile on). Make sure the plate sits flush.
- 3. Use Allen key to loosen the grub screw in the handle and fit it on the mixer body. Tighten the grub screw and fit the plug to cover the screw hole.
- 4. Carefully slide the outlet onto the spigot of adaptor until the back of the outlet abuts the cover plate, then tighten grub screws using Allen key.

Replacing Cartridge

- 1. Turn off hot and cold water supplies at isolating stop taps.
- 2. Carefully remove screw plug, loosen grub screw and remove handle. Unscrew dress ring on the mixer body, taking care not to damage the finish. Remove lock nut then lift out old cartridge.
- 3. Ensure inside of mixer body is clean. First check that seal is in position in base of new cartridge then fix new cartridge into mixer body. Taking care that two lugs on base of cartridge fit into mating holes in mixer body.
- 4. Screw on lock nut. The nut should be tightened to a torque of 12Nm. Replace dress ring and tighten firmly by hand.
- 5. Fit back handle on the mixer body and fit the plug to cover the screw hole.
- 6. Turn on isolating stop taps and check operation.